



HI-LITE MFG. CO., INC.

13450 Monte Vista Avenue

Chino, California 91710

Telephone: (909) 465-1999

Toll Free: (800) 465-0211

Fax: (909) 465-0907

www.hilitemfg.com

Mounting Instructions for Wall Mounted RLM Shade

1. Before installing fixture, disconnect power at main electrical box.
2. Screw shade onto end of arm using pipe joint compound or sealant tape on the arm threads, seat other end of arm into back plate with arm gasket in place.
3. Place back plate gasket over junction box.
4. Attach fixture black wire to outlet black wire and fixture white wire to outlet white wire using wire nuts provided.
5. Connect green fixture wire to grounding screw in junction box.
6. Attach back plate to junction box using screws provided.
7. Align fixture and secure by tightening set screws on black plate.

